

# E-Z DISHWASHER BRACKET

[www.ezdishwasherbracket.com](http://www.ezdishwasherbracket.com)



## INSTALLATION BEFORE PLACEMENT OF COUNTER TOP



### STEP 1:

Place the E-Z DISHWASHER BRACKET across the dishwasher opening on top of the cabinets with the raised panels facing up and the tabs flush to the cabinet facing. Secure the bracket with (4) #6X1/2" wood screws (provided). These are the same size screws used to anchor hinges to delicate cabinet doors.



### STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown – the bracket design will conceal any caulk squeeze out. This provides shock absorption to withstand the daily use of the dishwasher door.



### STEP 3:

The counter top can now be installed on top of the bracket. To install the dishwasher, attach the dishwasher straps to the E-Z DISHWASHER BRACKET using one of the many attachment holes. This will result in a secure and professional finished installation.



# E-Z DISHWASHER BRACKET

www.ezdishwasherbracket.com



## INSTALLATION AFTER PLACEMENT OF COUNTER TOP



### STEP 1:

For new or remodel installations where the counter top has already been placed, bend the end tabs of the E-Z DISHWASHER BRACKET into a 90 degree angle as shown, with the raised panels facing up.



### STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown. This provides shock absorption to withstand the daily use of the dishwasher door.



### STEP 3:

Put the bracket into place under the counter top with the tabs flush to the cabinet facing. Press bracket up against the counter top – the bracket design will conceal any caulk squeeze out.



### STEP 4:

Attach bracket to the cabinet sides with (4) #6X1/2" wood screws (provided). Caulk edges to provide a finished seal.



### STEP 5:

Attach the dishwasher straps to the E-Z DISHWASHER BRACKET using one of the many attachment holes. This will result in a secure and professional finished installation.

# E-Z DISHWASHER BRACKET

www.ezdishwasherbracket.com



## INSTALLATION WITH LAMINATE COUNTER TOP



### STEP 1:

For new or remodel installations where the counter top has already been placed, bend the end tabs of the E-Z DISHWASHER BRACKET into a 90 degree angle as shown, with the raised panels facing up.



### STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown. This provides shock absorption to withstand the daily use of the dishwasher door.



### STEP 3:

Put the bracket into place under the counter top with the tabs flush to the cabinet facing. Press bracket up against the counter top – the bracket design will conceal any caulk squeeze out.



### STEP 4:

Attach bracket to the cabinet sides with (4) #6X1/2" wood screws (provided). Caulk edges to provide a finished seal.



### STEP 5:

Attach the dishwasher straps to the E-Z DISHWASHER BRACKET using one of the many attachment holes. This will result in a secure and professional finished installation.